

# **PROSTAND**

Pipe Stand / Skid System

## **Safety Guidelines**

**Weight** - *Prostands* are designed to carry weight up to 2500 lb

**Spacing** - Suggested spacing for *Prostands* is every 20 feet.

### **Caution**

*Prostands* are a plastic reinforced material and can break if they are mishandled. They should be replaced if there are visible defects apparent.

*Prostands* should be used on level areas only.

*Prostands* Caution should be used when lowering pipe in, and when long sections are put on stands.